

## V Series Interface Part Number Guide

<b>Camino Interface</b>	<b>Part Number</b>
<b>Camino Advanced Monitor (CAM01)</b>	Must be obtained by INTEGRA (Camino manufacturer)
<b>Camino Bedside Monitoring Cable (PMIOMPM)</b>	Must be obtained by INTEGRA (Camino manufacturer)
<b>Camino PAC-1 IBP/ICT Pre-Amp Cable</b>	Must be obtained by INTEGRA (Camino manufacturer)
<b>Camino Adapter/Cable</b>	115-016069-00

<b>Vigilance CCO/SVO2 Interface</b>	<b>Part Number</b>
<b>Vigilance</b>	Must be obtained by Edwards Lifesciences (manufacturer)
<b>Serial Cable: Null Modem/ Female to Female</b>	0012-00-1275-01
<b>VDI Module</b>	0998-00-1802-0801A
<b>Analog Cable (Un-Terminated: Hospital Terminates per Clinical Engineering)</b>	0012-00-1801-02
<b>Analog Cable (Terminated)</b>	0012-00-1801-01
<b>Analog Cable Adapters (Required with Terminated Cable)</b> <ul style="list-style-type: none"> <li>• 2-3 Adapters required depending on model</li> </ul>	022-000113-00

<b>Vigilance II CCO/SVO2 Interface</b>	<b>Part Number</b>
<b>Vigilance II</b>	Must be obtained by Edwards Lifesciences (manufacturer)
<b>Serial Cable: Null Modem/Male to Female</b>	009-002237-00
<b>VDI Module</b>	0998-00-1802-0801A
<b>Analog Cable (Un-Terminated: Hospital Terminates per Clinical Engineering)</b>	0012-00-1801-02
<b>Analog Cable (Terminated)</b>	0012-00-1801-01
<b>Analog Cable Adapters (Required with Terminated Cable)</b> <ul style="list-style-type: none"> <li>• 2-3 Adapters required depending on model</li> </ul>	022-000113-00

<b>Vigileo CCO/SVO2 Interface</b>	<b>Part Number</b>
<b>Vigileo</b>	Must be obtained by Edwards Lifesciences (manufacturer)
<b>Serial Cable: Null Modem/Male to Female</b>	009-002237-00
<b>VDI Module</b>	0998-00-1802-0801A

<b>EV1000 CCO/SVO2 Interface</b>	<b>Part Number</b>
<b>EV1000</b>	Must be obtained by Edwards Lifesciences (manufacturer)
<b>Serial Cable: Null Modem/ Female to Female</b>	0012-00-1275-01
<b>VDI Module</b>	0998-00-1802-0801A

<b>Balloon Pump Interface</b>	<b>Part Number</b>
<b>DS Balloon Pump</b>	Must be obtained by Maquet (manufacturer)
<b>Analog Cable (Terminated)</b>	0012-00-1801-01

<b>DIAP (Datascope Improved ASCII Protocol)</b>	<b>Part Number</b>
<b>Serial Cable</b>	0012-00-1275-01
<b>VDI Module</b>	0998-00-1802-0801A

<b>Gas Module 3 Interface</b>	<b>Part Number</b>
<b>Gas Module 3</b>	0998-00-1900-01
<b>Serial Cable</b> 1' 6'	0012-00-1276-01 0012-00-1276-02
<b>VDI Module</b>	0998-00-1802-0801A

<b>Somanetics Interface</b>	<b>Part Number</b>
<b>INVOS 5100C System Monitor</b>	Must be obtained by Covidien (manufacturer)
<b>Serial Cable: Null Modem/ Female to Female</b>	312170 (Covidien) 0012-00-1275-01 (Mindray)
<b>VDI Module</b>	0998-00-1802-0801A

*Mindray DS USA, Inc. Document Revision*

DESCRIPTION:  <b>V Series Interface Part Number Guide</b>	DOCUMENT NO: <b>0002-08-50019</b>
	REVISION: <b>D</b>
	SHEET 4 of 4

REV. LETTER	CR NO. & EFF. DATE	DESCRIPTION
A	CR 40018	Original Release as Rev A
B	CR 40217	From Rev A to Rev B
C		From Rev B to Rev C